



# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

## Part #325-635

### EXO® Nose Block Device Kit For EXO® Original Model

Although the Original EXO 26 mask has a nose pocket to allow SCUBA-mask-style ear equalizing, the use of some hoods with thicker face seals or oversize gloves, or three-finger mitts, can make pinching the nose difficult. Proper installation and use of this device will make equalizing very easy.

Part #	Description	Qty
305-025	Nose Block w/pad and Velcro	1
330-801	1" Self Sticking Velcro-Loop	1.5 in.
345-055	Sandpaper	1

*\*Installation instructions on reverse.*

#### **⚠ CAUTION**

**Use only KMDSI original replacement parts. The use of other manufacturers' parts will interfere with the performance characteristics of your life support equipment and may jeopardize your safety. Additionally, any substitutions will void any warranties offered by KMDSI. When ordering spares, always insist on Kirby Morgan Genuine Parts.**

# Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com



## Installation Instructions

Read and understand all instructions before proceeding!

- 1) Remove all parts from the bag and check them against the front of this sheet to be certain all parts have been shipped.
- 2) At the back side of the regulator (inside the mask) is the inlet tube. This will be where the device is attached with the 1" wide **velcro "loop."** Place the velcro piece on the inlet tube as shown and mark the edges.
- 2) Using the enclosed sandpaper P/N 345-055, thoroughly rough up the area marked. Be sure to blow out any rubber particles removed by the sanding. **Failure to do so may result in the exhaust valve being held open by debris.** Clean the area with a lint-free towel and some Isopropyl (rubbing) alcohol. Allow to dry completely.

**NOTE: To achieve the best bond possible, it is suggested that you apply 1 (one) coat of wetsuit repair cement to the sanded area and allow to dry completely before installing the velcro.**

- 3) Remove the backing from the 1" wide velcro P/N 330-806 and carefully center it on the inlet tube in the marked area. Press it securely in place.
- 4) The nose block device P/N 305-025 can now be positioned up or down on the velcro as desired for the best equalizing. The bend angles may also be changed using pliers.

Once in the water, on decent, simply push inward on the regulator, toward the face, to block the nose for equalizing. When not needed, the device can be removed to allow normal equalizing by pinching the nose.

