



Kirby Morgan Dive Systems, Inc.®

1430 Jason Way Santa Maria, California 93455

Phone: 805/928-7772 Fax: 805/928-0342

www.KirbyMorgan.com email: kmdsi@KirbyMorgan.com

Installation Instructions

505-010

Latch Catch Assembly: Pull Pin Type

(For use on SuperLite 17A/B Helmets)

The hole pattern in the Pull Pin Latch Catch Body is identical to the hole pattern on the earlier Push Pin Latch Catch Body.

Remove the existing Latch Catch Assembly and clean the mounting surface on the yoke.

Use the machine screws furnished with the Pull Pin Latch Catch Assembly, as they are longer than the original screws.

Refer to Diagram: To prevent cross threading the two screws (2&3) in the area of the channel, first start the screw in #1 position by hand. Next locate the #2 screw hole and start it by hand. Both screws should remain rather loose until the #3 hole is started, also by hand. When all three screws are properly started, then tighten them evenly with a screwdriver until snug.

